








CORNWALL CONNECTICUT SUBREGIONAL BASINS AND SURFACE WATER FLOW DIRECTIONS

Explanation


-  Town Boundary
-  Subregional Watershed Boundary
- 4201** Subrg. Basin ID# - as designated by CTDEP
-  Watercourse  Open Water
-  Basin Outlet
-  Surface Water Flow Direction

The table provides statistics for each subregional basin. Shown are the areas of the basin within the town, the percentage for that area, and the percent of the town covered by each basin.

Sbas_no	Acres In Tw	Percofb	Percoftwn
6000	9288.88	2.3	31.3
6008	3647.11	100.0	12.3
6010	8503.22	100.0	28.6
6011	0.01	0.0	0.0
6012	10.97	0.3	0.0
6200	4446.68	26.1	15.0
6700	2136.11	4.7	7.2
6701	43.90	0.6	0.1
6702	1630.10	24.4	5.5



Town Area: 29707 Acres



Digital layers provided by the CTDEP.
Map composed by the NEMO project.
For educational purposes only.

